www.ersatzteil-service.de



REPAIR PARTS MANUAL

MODEL NO. EDITION 1

MFG. ID. NO. 96141011700

Rotary Lawn Mower

McCULLOCH

532 40 27-08 Rev. 1 01.06.06 BY

Printed in U.S.A.

Ihr Ersatzteilspezialist im Internet

www.ersatzteil-service.de

ROTARY LAWN MOWER - - MODEL NO. EDITION 1 (96141011700) - PRODUCT NO. 961 41 01-17



Ihr Ersatzteilspezialist im Internet

ROTARY LAWN MOWER - - MODEL NO. EDITION 1 (96141011700) - PRODUCT NO. 961 41 01-17

KEY NO.	PART NO.	DESCRIPTION
1	532 19 25-17	Upper Handle
2	532 15 36-05	Lower Handle
3	532 14 67-71	Control Bar
4	532 18 35-67	Cable, Engine Zone Control
5	532 19 15-74	Handle Bolt
6	532 19 19-38	Handle Knob
7	532 05 17-93	Hairpin Cotter
8	532 06 64-26	Wire Tie
9	532 18 04-79	Rear Door Kit (Includes Key Numbers 16 & 17)
10	532 12 84-15	Pop Rivet
11	532 18 25-38	Support Bracket, LH
12	532 18 25-39	Support Bracket, RH
13	817 06 04-10	Screw 1/4-20 x 5/8
14	532 18 25-43	Handle Bracket Assembly, LH
15	532 18 25-45	Handle Bracket Assembly, RH
16	532 18 00-71	Spring, Rear Door, LH
17	532 18 00-72	Spring, Rear Door, RH
18	532 13 20-04	Locknut, Hex, Keps 1/4-20
19	532 19 47-88	Rope Guide
20	532 17 92-05	Foot Guard, C.E.
21	532 05 45-83	Screw, Tapping 1/4-20 x 1/2
22	532 18 49-41	Engine Pulley
23	532 18 77-23	Hi-Pro Key
24	- - -	Engine, Honda, Model Number GCV160 (order parts from engine manufacturer)
25	532 15 04-06	Screw, Hex Head, Rolled 3/8-16 x 1-1/8
26	532 14 52-12	Nut, Hex, Flanged
27	532 40 25-95	Wheel & Tire Assembly, Rear 12"
28	532 16 08-28	Shoulder Bolt 5/16-18 x .33
30	532 40 25-71	Axle Arm Assembly, Rear, RH
31	532 70 10-37	Selector Knob
32	532 19 01-57	Selector Spring
33	873 80 05-00	Locknut, Hex
34	532 40 25-72	Axle Arm Assembly, Rear, LH
36	532 18 41-93	Bolt
37	532 15 00-78	Thread Cutting Screw w/Sems 5/16-18 x 3/4
38	819 11 22-06	Spacer
40	532 19 09-39	Mounting Bracket, Debris Shield
41	532 19 23-25	Screw, Hex Washer Head
43	532 18 87-84	Debris Shield
44	532 40 07-51	Kit, Lawn Mower Housing (Includes Key Numbers 10, 11, 12 and 45)
45	532 18 21-66	Danger Decal
46	532 18 46-32	Blade Adapter
47	532 19 93-77	Blade, 21"
48	532 85 10-74	Hardened Washer
49	532 85 02-63	Helical Washer 3/8-24 x 1-3/8 Grade 8
50	532 85 10-84	Machine Screw, Hex 3/8-24 x 1-3/8 Grade 8
59	532 17 50-71	Discharge Deflector
60	532 17 57-35	Hinge Bracket
61	532 19 30-00	Spring, Hinge
62	532 17 56-50	Rod, Hinge
63	873 80 04-00	Nut, Hex
64	532 17 50-66	Mulcher Door
65	532 19 74-80	O-Ring
66	532 08 83-48	Washer, Flat 3/8
96	532 19 79-91	Clip, Cable
- -	532 18 21-34	Decal, Self-Propelled, Internal (not shown)
- -	532 40 27-11	Operator's Manual, European
- -	532 40 27-09	Operator's Manual, Scandinavian
- -	532 40 27-12	Operator's Manual, East Bloc
- -	532 40 27-10	Operator's Manual, Baltic
- -	532 40 27-08	Repair Parts Manual, English

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

Ihr Ersatzteilspezialist im Internet
www.ersatzteil-service.de

www.ersatzteil-service.de

ROTARY LAWN MOWER - - MODEL NO. EDITION 1 (961411011700) - PRODUCT NO. 961 41 01-17



Ihr Ersatzteilspezialist im Internet

ROTARY LAWN MOWER - - MODEL NO. EDITION 1 (96141011700) - PRODUCT NO. 961 41 01-17

KEY NO.	PART NO.	DESCRIPTION
1	532 18 45-88	Cable Assembly, Drive Control
2	532 19 10-39	Bearing, Wheel Adjuster
3	532 17 52-62	Pan Head Tapping Screw #10-24 x 2-3/4
4	532 15 87-55	Hex Washer Head Screw 1/4-20 x 2.12
5	532 17 54-36	V-Belt
6	532 15 04-95	Spring Retainer
7	532 19 17-30	Nut, Hex, Flanged 1/4-20
9	532 08 39-23	Locknut, Hex
11	532 40 25-67	Wheel & Tire Assembly, Front 8"
12	812 00 00-58	E-Ring
13	532 75 00-03	Pinion
14	532 18 94-03	Dust Cover
15	532 19 10-17	Pawl, Drive
16	532 06 77-25	Washer 1/2 x 1-1/2 x .134
18	532 70 10-37	Selector Knob
28	532 18 14-67	Drive Cover
32	532 19 41-26	Drive Pulley
35	532 19 51-10	Kit, Wheel Adjuster, LH (Includes Knob and Bearing)
36	532 19 49-35	Gear Case Assembly (See Breakdown)
38	873 80 04-00	Locknut, Hex 1/4-20
40	532 13 70-90	Spring
41	532 19 51-07	Kit, Wheel Adjuster, RH (Includes Knob and Bearing)

KEY NO.	PART NO.	DESCRIPTION
54	532 19 54-51	Grassbag Assembly
55	532 17 57-39	Driveshaft Cover
57	532 19 46-43	Frame, Grassbag
60	532 18 34-97	Case, Lower
61	532 18 34-98	Case, Upper
62	532 18 34-99	Gear, 27 Teeth
63	532 18 35-00	Lever, Clutch
64	532 18 35-01	Spring, Return
65	532 18 35-02	Shaft, Input
66	532 18 35-03	Dog, Movable
67	532 18 35-04	Dog, Fixed
68	532 18 35-05	Wire, Formed
69	532 18 35-06	Bearing, Ball
70	532 18 35-07	Fork, Shift
71	532 18 35-08	Seal, Output Shaft
72	532 18 35-09	Washer
73	532 18 35-10	Seal, Case
74	532 18 35-11	Bushing
75	532 19 66-13	Shaft, Output
76	532 18 35-13	Screw
77	532 18 35-14	Seal, Input Shaft

NOTE: Use Dow Corning #709 to reseal Gear Case Halves.

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

Ihr Ersatzteilspezialist im Internet
www.ersatzteil-service.de

SERVICE NOTES

SERVICE NOTES

www.ersatzteil-service.de

LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of two (2) years from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

1. This warranty does not apply to the engine. Please contact your nearest dealer where they will send the machine to the engine manufacturer.
2. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by your dealer.
3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
4. The Warranty period for any products used for rental or commercial purposes is limited to 90 days from the date of original purchase.
5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
7. In case of any problem within the boundaries of this warranty, contact the nearest department store, indicate the model number, serial number and the date of purchase of your machine. This warranty does not apply to accidental damages. All implicit warranties are limited to the same time frames. Or contact:

E.M. Services
54 Rue Lambrechts
92400 Courbevoie
France
Telephone: (1) 46678078
Fax: (1) 46678095

THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES. ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN.

McCULLOCH

www.electrolux.com/mcculloch

Ihr Ersatzteilspezialist im Internet